



GUANGDONG DETECTION CENTER OF MICROBIOLOGY

REPORT FOR ANALYSIS

Report №.	2020SP2265R01E				
Name of Sample	UVC Sterilization Lamp				
Applicant	Zhongshan Keyun Electrical Appliances Co., Ltd.				
Test Type	Patrustment Test				
	检验检测专用章				

Address: Building 66, No.100 Central Xian Lie Road, Guangzhou, China

Postcode: 510070

Tel: +86 20 87137666

Fax: +86 20 87137668

Website: www.gddcm.com







GUANGDONG DETECTION CENTER OF MICROBIOLOGY

REPORT FOR ANALYSIS

Report №.: 2020SP2265R01E Verification Code: 78540362



Name of Sample	UVC Sterilization Lamp	Test Type	Entrustment Test					
Applicant	Zhongshan Keyun Electrical Appliances Co., Ltd.	Address	No.42, Haiwei Road, Liexiyi, Xiaolan Town, Zhongshan City, Guangdong Province, P.R.China					
Sample Source	Submitted for Testing by the Applicant	Sample Quantity	One					
Spec and Lot № of Sample	SJD-38W	State and Characteristic	Machine					
Sample Received Date	2020-03-31	Test Completion Date	2020-04-10					
Test Standard and Method	Technical Standard for Disinfection (Ministry of Health, Edition 2002), section 2-2.1.5.4							
Item Tested	Sterilization and disinfection equipment disinfection efficacy test: UV lamp							
Testi Testi Testi Testi	Test Test Test Test Test Test Test Test	esti Testi Testi Testi	Test Test Test Test Test Test Test Test					
seting seting esting	Ceting sting esting sting		A Stind Stind Stind Stind					
Grido Grido Gri	The test data of the sample(s) is attached to the page(s) of this report.							
Test Conclusion	Elusion							
Stricto Lear Childo Chil	o Test o Test of test of Test of test of		Tegri Tegri Tegri Tegri Tegri Tegri Te					
Testinds Testinds Testinds Gride Grides Grid	o Testino Test	Issu	e Date: 2020-04-20					
Remarks	Manufacturer/Supplier: Zhongshan Keyun Electrical Appliance: Co. Ltd. (Provided by the applicant)							

Editor: L'yungian

Verifier: Liang Daging

Approver: Li Lianggiu







GUANGDONG DETECTION CENTER OF MICROBIOLOGY

ANALYSIS AND TEST RESULT

Report №:: 2020SP2265R01E

1. Action Time: 30min 2. Action distance: 10cm

3. Results:

	Test organisms	Test group	Average cfu of testing groups (cfu/piece)	Average cfu of positive controls (cfu/piece)	Sterilization logarithm (KL)	Sterilization rate (%)
6	<u> </u>	1	<5	2.0×10^6	>5.58	>99.99
	Escherichia coli 8099	2	, in 5 , in 5	1.8×10 ⁶	>5.58	>99.99
		3.00	<5	1.9×10^{6}	>5.58	>99.99
			Average	1.9×10^{6}	>5.58	>99.99
Testiff Co	Staphylococcus aureus ATCC 6538	2051 A	5,5 < 5,5	4. 0×10 ⁶	>5.90	>99.99
		2.00	<5 Kd°	4. 0×10 ⁶	>5.90	>99.99
		3	<5	4. 1×10 ⁶	>5.90	>99.99
		O COSTITION	Average	4. 0×10 ⁶	>5.90	>99.99
હ	Candida albicans	1 ido	<5	1.2×10^{6}	>5.39	>99.99
		2	<5	1.2×10^{6}	>5.39	>99.99
	ATCC 10231	3	e de la companya de l	1. 3×10 ⁶	>5.39	>99.99
		do mido	Average	1.2×10^{6}	>5.39	>99.99

(Blank below





Report №.: 2020SP2265R01E

Notice Items

- 1. The Test report is invalid if not affixed with Authorized Stamp of Test and Paging Seal.
- 2. The Test report is invalid without signature of verifier and approver.
- 3. The Test report is invalid if being supplemented, deleted or altered.
- 4. Without prior written permission, the report cannot be reproduced, except in full.
- 5. Unless otherwise stated, the results shown in this test report refer only to the sample(s) submitted.
- 6. Any dispute of the report must be raised to the testing body within 15 days after the report is received, exceeding which the dispute will not be accepted.
- 7. For the tested sample(s) submitted by the applicant, the sample information in the test report is provided by the applicant and the laboratory is not responsible for its authenticity.

